



PLUGS ARE NOT
SUITABLE AS
DISCONNECTS
USER MUST SUPPLY
SUITABLE
DISCONNECTS.

VOLTAGE-120VAC
14 AMPS 1 HP
SINGLE PHASE 50% Hz.
20 AMP BRANCH
CIRCUIT PROTECTION
TO BE PROVIDED BY
OTHERS DURING FIELD
INSTALLTION FOR
EACH CIRCUIT.

TOLERANCES $\pm 1/32$ " FRACTIONAL DIMENSIONS
TOLERANCES $\pm .005$ " DECIMAL DIMENSIONS
UNLESS OTHERWISE SPECIFIED

INFORMATION CONTAINED HEREIN IS
PROPRIETARY TO EAGLE PNEUMATIC, INC.
ALL RIGHTS RESERVED

TITLE:
STATION, TYPE II
6 INCH DOWN-SEND

MATERIAL:

FINISH:

REV. 4-12/29/04
1.11/18/97
2.-3/13/03
3.-8/5/03

DRAWN: JAC
CADFILE\ A29

DATE: 11/18/97



EAGLE
PNEUMATIC, INC.
(863)644-4870

DRAWING NO.

S-151

APPROVED:

ISSUE
4